


BOATING SAFETY INNOVATIONS

by



Mounted Above Windshield Fig. 1

Mounted Below Windshield Fig. 2



MOUNTING INSTRUCTIONS FOR THE CIPA BOATING SAFETY MIRROR™

Thank you for your purchase of the 4x8-inch universal CIPA BOATING SAFETY MIRROR™. This mirror is for water skiing and general boating Safety. The instructions below should Help you get the most benefit from your new mirror. For maximum rear view safety, add a WING II™ Universal sidemount mirror.
-SAFE BOATING!

MOUNTING YOUR MIRROR

Placement of the mirror is a matter of personal preference. Always avoid mounting any mirror in a place that will block forward vision.

Your CIPA BOATING SAFETY™ mirror is designed to universally mount above or below the windshield frame, giving you maximum rear view with a few simple adjustments. Mounting the mirror so that the mirror head is above the windshield frame (and driver's head) is preferable because the mirror is not obstructed by passengers, or the drivers body. This mounting position will give the driver Maximum benefit of your new mirror.

Regardless of how you mount your new CIPA mirror, be sure to affix the anti-scratch pad to your windshield frame to protect it. Refer to fig. 1 for standard frames (thin plate) and fig 2 for frames thinner than 5/8-inch (thick plate).

ABOVE THE WINDSHIELD

To mount the Boat Mirror above the windshield frame follow the instructions below while referring to figure 1.

1. Loosen the mirror head mounting arm screw so as to disengage the locking teeth.
2. Place the clamping bracket over the windshield frame (knobs on inside of boat) and securely tighten the thumb knobs on the clamping bracket.
 - Be sure to affix the anti-scratch pad to your windshield frame for protection.
3. Move the mirror head/arm into a position similar to that in figure 1. Tighten the phillips head screw so that the locking teeth are firmly engaged. Fine Tune as needed.

BELOW THE WINDSHIELD

Mounting the mirror below the windshield frame can restrict forward and rear view. The best place to mount the mirror in down position is on the walk-thru windshield.

1. Loosen the phillips head screw to disengage the locking teeth.
2. Place the clamping bracket over the windshield frame (knobs on outside of frame) and tighten thumb knobs.
3. Move the mirror into position and tighten the phillips head screw (Fig. 2).

MOUNTING PLATES

Two different Anti-scratch mounting plates were included with your new mirror. Mounting plate A is for standard thickness windshield frames (5/8-inch to 3/4-inch). See Fig 1. Peel back the paper on the Adhesive and place on the frame where you will mount the mirror.

Plate B (see Fig 2) is for frames thinner than 5/8-inch. This plate goes into the Clamping bracket of the mirror.

WARNING

Objects in the mirrors are closer than they appear. Practice getting used to this difference so you can better judge distances in the mirror.